

Date: 24th October, 2007

Affected Products: NI-2008 Gas Release Module

Due to the increased potential for errors when utilizing gas release it is recommended that the following procedures and precautions be followed when using any Notifier gas release product to prevent an unintended discharge;

- Read the manual for the NI-2008 gas release module and Local Control Station (if fitted) to fully understand the intended operation of the system.
- Conduct a full system test on the FIP and gas release module before connecting the gas head output.
- The gas head output should be disconnected when powering up the system.
- The gas head output should be disconnected before performing maintenance or tests on any part of the system.
- Ensure correct switch settings on the gas release module for delay time and mode settings.

If you have any question please do not hesitate to contact me.

Sincerely,



James Edwards
Product Manager